







WELD ON LIFTING POINT - PELP

Load Rating (WLL) & Dimensions


The weld on lifting point must be positioned on the load so that twisting or turning is avoided


- For single leg lift, the lifting point should be vertically above the centre of gravity of the load.
- For two leg lifts, the lifting points must be equidistant to/or above the centre of gravity of the load.
- For three and four leg lifts, the lifting points should be arranged symmetrically around the centre of gravity in the same plane.

Working Load Limits – Please see the Table below to determine WLL on 2, 3 or 4 leg lifts

Working Load Limits (tonnes)								
	Single	2, 3 or 4 point Maximum Included Angle						
Part No.	Point	60°	90°	120°				
PELP040	0.4	0.7	0.5	0.4				
PELP080	0.8	1.4	1.1	0.8				
PELP160	1.6	2.8	2.2	1.6				
PELP250	2.5	4.4	3.4	2.5				

Dimensions									
Part No.	WLL (t)	В	С	D	E	Weight (kg)			
PELP040	0.4	28	23	13.8	42	0.18			
PELP080	8.0	34	28	16.5	53.8	0.32			
PELP160	1.6	44	33	20	61.8	0.62			
PELP250	2.5	57	38	24	67	0.93			





Townley Drop Forge Pty Ltd

96 John Street, P.O. Box 12, Brunswick East, Victoria, 3057

Tel: +61 3 9387 4155 Fax: +61 3 9387 3685

Email: sales@townleydropforge.com.au Web: www.townleydropforge.com.au